

How to install Seskion License -Seskion GmbH-

Content:

- Get Seskion License
- License activation
 - Saving the file in the right folder
 - Loading the file in the software

Version:	(1.0) 05.04.2022 – Creation		



Get Seskion License

If you have acquired a Software license from Seskion GmbH, which is either a PC-ID bound license or a sensor model, then you will receive a file named "seskionLicense.xml" via E-Mail from one of our colleagues. If this does not happen, please contact <u>sales@seskion.de</u>.

License activation

When you have received the E-Mail with the license, you must save the file on your PC respectively on the PC to which the Simulyzer is connected. There are two methods how you can save the file:

1. Saving the file in the right folder

Install the GUI Software on the test computer. If you have problems with this, I recommend the Application Note "Simulyzer-Software Operating Help". There everything is described to the download of the Software.

If you have downloaded the Windows GUI, you can simply drag and drop the file into the folder of the respective Simulyzer. In the example screenshot you can see how the file is moved to a PSI5-Simulyzer folder. The folders of the Simulyzers are mostly listed under *C:\Program Files (x86)\SesKion GmbH*.

Bieser PC → Windows (C:) → Program	me (x86) > SesKion GmbH	> PSI5-Simulyzer	~	ව , PSI5-Simulyzer' durchsuchen
Name	Änderungsdatum	Тур	Größe	
API	04.11.2021 12:21	Dateiordner		
DataModels	04.11.2021 12:21	Dateiordner		
Driver	04.11.2021 12:21	Dateiordner		
PSI5_Templates	04.11.2021 12:21	Dateiordner		
	04.11.2021 12:21	Dateiordner		
dacasr.dll	15.07.2021 17:26	Anwendungserwe	2.252 KB	
DefaultColors	15.07.2021 17:26	XML-Dokument	4 KB	
defaultsettings	15.07.2021 17:26	XML-Dokument	42 KB	
™ DPInst	15.07.2021 17:26	Anwendung	901 KB	
₹ dpinst64	15.07.2021 17:26	Anwendung	1.026 KB	
DpInstWrapper	05.10.2021 13:34	Anwendung	7 KB	
DpInstWrapper.exe.config	15.07.2021 17:26	CONFIG-Datei	1 KB	
😭 EmbeddedUSICopyrights	15.07.2021 17:26	Kompilierte HTML	24 KB	→ Nach PSI5-Simulyzer verschieben
👬 FirmwareUpdate	05.10.2021 16:41	Anwendung	1.920 KB	
fw_0101_0109.iic	15.07.2021 17:26	IIC-Datei	6 KB	
fw_0202_0109.iic	15.07.2021 17:26	IIC-Datei	6 KB	
Adf5dll.dll	15.07.2021 17:26	Anwendungserwe	820 KB	
ListViewPrinter.dll	15.07.2021 17:26	Anwendungserwe	56 KB	
mainsettings	15.07.2021 17:26	XML-Dokument	218 KB	
Nevron.Presentation.dll	22.04.2021 11:40	Anwendungserwe	4.340 KB	
Nevron.System.dll	22.04.2021 11:40	Anwendungserwe	432 KB	
Revron.UI.WinForm.Docking.dll	22.04.2021 11:40	Anwendungserwe	704 KB	

2. Loading the file in the Software

Install the GUI Software on the test computer. If you have problems with this, I recommend the Application Note "Simulyzer-Software Operating Help". There everything is described to the download of the Software.

If you have downloaded the Windows GUI you have to open it now. Click on the *Help* menu item to go to the *About* menu. A new window opens here.

File View Tools Help ECU Help PSI5 Bus Configuratic About

In the window you now go to *Product License* and can now read in the license via *Install License*, no matter where it is located on your computer and what it is called. You can also request additional licenses directly from us via *Request License*.

🔛 About PSI5	- Simulyzer
	SesKion
	PSI5-Simulyzer
	PSI5-Simulyzer SesKion GmbH Product License
	SESION_LICENEE_FILE not set
	Close